

## Infrared and IR-Fusion® Modes by Model

	Ti90	Ti95	Ti100	Ti105	Ti110	Ti125	TIR105	TiR110	TIR125
Full AutoBlend™ (min IR mode)					•	•		•	•
Full AutoBlend™ (mid IR mode)				•	•	•	•	•	•
Max IR (Full Thermal)	•	•	•	•	•	•	•	•	•
Full Visible	•	•		•	•	•	•	•	•
Picture-in-Picture AutoBlend™ (min)					•	•		•	•
Picture-in-Picture AutoBlend™ (mid)				•	•	•	•	•	•
Picture-in-Picture AutoBlend™ (max)		•		•	•	•	•	•	•

Note: Ti105 and TiR105 models have aligned IR-Fusion from 1.2 m to 4.6 m (4 ft to 15 ft).

## Ti90, Ti95 Ti100, Ti105, Ti110, Ti125 TiR105, TiR110, TiR125 Thermal Imagers

Quick Reference Guide

## ∧ Marning

To prevent possible electrical shock, fire, or personal injury, read all "Safety Information" before you use this Product.


Go to <u>www.fluke.com</u> to register your product and find more information.

To view, print, or download the latest manual or supplement, visit <u>us.fluke.com/usen/support/manuals</u>.

To download SmartView® software visit <a href="www.fluke.com/">www.fluke.com/</a> smartviewdownload.

To download the Fluke Connect<sup>™</sup> app, go to iTunes or Google app store and download Fluke Connect.





	Ti90 Ti95 Ti100	Ti105 TiR105	Ti110 Ti125 TiR110 TiR125
•	•	•	•
①	•	•	•
SD	•	•	•
[111]1	•	•	•
		•	•
<u> •</u>			•
<b>4)))</b>			•

